
MODEL 0402 ETHERNET POCKET HUB SPECIFICATIONS

Standards

IEEE 802.2, 802.3

Physical

Dimensions

4.80" X 2.77" X 0.95" (122mm x 70mm x 24mm)

Input Power

Power Supply Adapter

AC Input:

TN PN	Requirement	Location
3518	120 volts, 60 hertz, 28 watts	USA/Canada/Mexico
3516	230 volts, 50 hertz, 28 watts	Europe
3514	100 volts, 50-60 hertz, 28 watts	Japan
3517	240 volts, 50 hertz, 28 watts	United Kingdom
3515	240 volts, 50 hertz, 28 watts	Australia

DC Output:

9 volts at 500 mA maximum

MTBF

43,000 hours

Environment

Temperature:	0-50°C (32° to 122° F)
Humidity	10-90%, non condensing
Altitude	0-10,000 feet

Warranty

5 years


Ethernet Pocket Hub™ Model 0402 (E-TBT-HB-0402)

7349.E

For assistance in installing, using, or maintaining the TRANSITION Networks Model 0402 Ethernet Pocket Hub, contact TRANSITION Networks Technical Support at:

(800) 260-1312

or contact your local distributor.



CAUTION: RJ connectors are NOT INTENDED FOR CONNECTION TO THE PUBLIC TELEPHONE NETWORK. Failure to observe this caution could result in damage to the public telephone network.

Der Anschluss dieses Gerätes an ein öffentliches Telekommunikationsnetz in den EG-Mitgliedstaaten verstößt gegen die jeweiligen einzelstaatlichen Gesetze zur Anwendung der Richtlinie 91/263/EWG zur Angleichung der Rechtsvorschriften der Mitgliedstaaten über Telekommunikationsendeinrichtungen einschliesslich der gegenseitigen Anerkennung ihrer Konformität.

Compliance Information

UL Listed

C-UL Listed (Canada)

CISPR/EN55022 Class A

FCC Regulations

This equipment has been tested and found to comply with the limits for a class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at the user's own expense.

Canadian Regulations

This digital apparatus does not exceed the Class A limits for radio noise for digital apparatus set out on the radio interference regulations of the Canadian Department of Communications.

European Regulations

Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Copyright Restrictions

© 1995, 1996 TRANSITION Networks Inc.

All rights reserved. No part of this work may be reproduced or used in any form or by any means – graphic, electronic, or mechanical – without written permission from TRANSITION Networks Inc.

Trademark Notice

All registered trademarks and trademarks are the property of their respective owners.

10Base2 Cable Specifications

The physical characteristics of the 10Base2 cable must meet or exceed IEEE 802.3 10Base2 specifications.

Cable Characteristics:

Cable type:	Stranded Coaxial RG58 (ThinNet)
Impedance:	50 Ω @ 10 MHz
Mutual Capacitance:	24 pF/ft \pm 20% @ 10 MHz
Maximum Cable Length:	185 meters (610 feet)
Maximum number network connections:	30
Minimum distance between connections:	0.5 meters (1.6 feet)

Terminate 10Base2 cable at one end using a 50 ohm terminator and at the other end using a 50 ohm terminator grounded to earth ground.

10BaseT Cable and Connector Specifications

The physical characteristics of the 10BaseT cable must meet or exceed IEEE 802.3 10BaseT specifications.

10BaseT Cable Characteristics:

Category 3 wire or better is required; category 5 wire is recommended. Either shielded twisted pair (STP) or unshielded twisted pair (UTP) can be used. **DO NOT USE FLAT OR SILVER SATIN WIRE.**

Category 3:

Gauge	24 to 22 AWG
Attenuation	28 dB/1000' @ 10 MHz
Differential Characteristic Impedance	100 Ω \pm 10% @ 10 MHz


Category 5:

Gauge	24 to 22 AWG
Attenuation	20 dB/1000' @ 10 MHz
Differential Characteristic Impedance	100 Ω \pm 10% @ 10 MHz

Maximum Cable Length: 100 meters (330 feet)

10BaseT Connector Characteristics:

The two active pairs in a 10BaseT network are pins 1 & 2 and pins 3 & 6. Use only dedicated wire pairs (such as blue/white & white/blue, orange/white & white/orange) for the active pins. 10BaseT cable for unlike devices (such as hub to terminal device) must be configured as straight through; 10BaseT cable for like devices (such as hub to hub or terminal device to terminal device) must be configured as crossover.



ETHERNET CABLE SPECIFICATIONS

Maximum number of terminal devices on Ethernet network: 1024

10Base5 Cable and Connector Specifications

The physical characteristics of the 10Base5 cable must meet or exceed IEEE 802.3 10Base5 specifications.

10Base5 Cable Characteristics:

Cable type:	RG8 Solid Coaxial (ThickNet)
Impedance:	50 Ω @ 10 MHz
Capacitance:	26pF/ft
Maximum Cable Length:	500 meters (1650 feet)
Maximum number network connections:	100
Minimum distance between connections:	2.5 meters (8.2 feet)

Terminate 10Base5 cable at one end using a 50 ohm terminator and at the other end using a 50 ohm terminator grounded to earth ground.

AUI Cable and Connector Specifications

The cable is a special 4-pair individually shielded with an overall braided shield.

Maximum AUI Cable Length: 50 meters (165 feet)

AUI Connector Characteristics:

AUI Port:	Male DB-15 with locking posts.		
AUI Connection:	Cable shell must be grounded.		
Connector Legend:	1 Logic Ref.	6 Power Return	11 Logic Ref
	2 Collision+	7 N/C	12 Receive
	3 Transmit+	8 Logic Ref.	13 Power
	4 Logic Ref.	9 Collision--	14 Logic Ref.
	5 Receive+	10 Transmit-	15 N/C

10BaseFL Cable and Connector Specifications

The physical characteristics of the 10BaseFL cable must meet or exceed IEEE 802.3 10BaseFL specifications.

10BaseFL Cable Characteristics:

Fiber Optic Cable Recommended:	62.5/125 μm multimode fiber
Optional:	100/140 μm multimode fiber
	85/125 μm multimode fiber
	50/125 μm multimode fiber
Fiber Optic Transmitter Power:	Average power: -15.0 dBm
	Peak power: -12.0 dBm ±1dBm
Fiber Optic Receiver Sensitivity:	Average sensitivity: -27.4 dBm
	Bit error rate: ≤10 ⁻¹⁰

Maximum Cable Length: 2000 meters (6500 feet)

10BaseFL Connector Characteristics:

ST type connectors (SMA type available upon request)

Table of Contents


1 INTRODUCTION	1
The 0402 Ethernet Pocket Hub	1
0403 Pocket Hub Features	1
Networking the 0402 Pocket Hub	2
0402 Ethernet Pocket Hub Connectors	3
RJ-45 Connectors	3
Power Supply Adapter Connector	3
0402 Ethernet Pocket Hub Status Indicators	4
Power LED	4
Link/Transmit LED	4
2 SITE CONSIDERATIONS	5
Ensuring Compliance with Ethernet 802.3	6
Segment Number	6
Ensuring Correct 10BaseT Configuration	7
Straight Through/Crossover Cable Orientation	7
Straight Through/Crossover Pin Specifications	8
3 INSTALLATION	9
Unpacking 0402 Pocket Hub	9
Connecting 10BaseT Cable	10
Connecting Power to 0402 Pocket Hub	10
4 OPERATION	11
Monitoring Power LED	11
Monitoring Link/Transmit LEDs	11
5 MAINTENANCE	12
Fault Isolation	12
Technical Support Contact	12
WARRANTY STATEMENT	13
CABLE SPECIFICATIONS	15
0402 ETHERNET POCKET HUB SPECIFICATIONS	17

1. INTRODUCTION

This guide is intended for the system or network administrator responsible for installing and monitoring a TRANSITION Networks 0402 Ethernet Pocket Hub. A working knowledge of local area network (LAN) operations, including familiarity with communications protocols used on interconnected LANs, is assumed.

The 0402 Ethernet Pocket Hub

The Model 0402 10BaseT 4-Port Ethernet Hub (E-TBT-HB-0402), is a low cost Ethernet repeater. Designed to meet IEEE 802.3 10BaseT standards, the 0402 Pocket Hub is a fully functional repeater in a compact (4.80" X 2.77" X 0.95") case.



0402 Ethernet Pocket Hub Features

- automatic link partitioning (jabber function isolates network failures)
- preamble regeneration
- automatic polarity detection and correction

The sole purpose of this remedy shall be provided the customer with the replacement or repair of non-conforming goods in the manner described in this Warranty statement. This exclusive remedy shall not be deemed to have failed of its essential purpose so long as TN is willing and able to repair or replace the defective item(s) or refund the purchase price.

TN reserves the right to inspect products claimed to be defective under warranty either at the customer's location or at TN's plant. TN assumes no liability for liability charges incidental to the adjustment, service, repairing, removal or replacement of the product, or other costs, or the expense of repairs made outside of its factory, except when made with TN's prior written consent. Additionally, Transition Networks reserves the right to charge for all testing and shipping incurred, if after testing, a return is classified as "No Problem Found".

TN's total liability in connection with the products and their installation to all persons and from all causes in the aggregate, whether in contract, tort, or strict liability, shall not exceed the amount paid to TN for the product directly related to the alleged damage. However, in no event shall TN have any liability to a customer or any third party for products manufactures according to the customer's specifications.

C. Return Procedure

The customer must follow this procedure for the return of defective items:

1. Locate the serial number(s) of the item(s) to be returned.
2. Determine the date the item(s) was received.
3. Contact Transition Networks Technical Support to determine if the problem can be corrected on site.

If not, and the product is covered by warranty, then:

- Call the distributor directly or contact TN.
- Request a Return Material Authorization (RMA).
- Ship the item, prepaid in original packaging to Transition Networks at the above address.
- Include the RMA number on the outside of the carton and/or on the Packing List.
- Include a copy of the RMA form.
- Include a copy of the original invoice or packing list (if possible) to expedite processing.
- The item(s) may be shipped by the customer or the distributor.
- Transition Networks will repair or replace the unit, at TN's discretion, and cover the cost of the return freight to the distributor or to the customer, whichever requested the RMA number.

If the item(s) was received **more than five years ago**, or if the item(s) is **no longer covered by warranty** for other reasons, then:

- Call the distributor or contact TN.
- Request a Material Repair Authorization number (MRA).
- Ship the item(s), prepaid, in the original packaging to Transition Networks at the above address.
- Include the MRA number on the outside of the carton add/or on the Packing List.
- Include a copy of the MRA form.
- Include a copy of the original invoice or packing list (if possible) to expedite processing.
- Only the customer (end-user) may send the items(s) to TN.
- TN will contact the customer after the item(s) have been received, inspected, and a cost estimate of the repair determined.
- The repair charges may be billed, with customer's approval, though the distributor, or on a prepaid or C.O.D. basis directly to the customer. The charges will include the cost of shipping.

The return authorization numbers are valid only for 90 days from the date issued.

Warranty Statement

A. Five Year Warranty

Transition Networks, Inc. (TN) warrants, for a period of five years, that TN products (with the exception of power supplies and fans that TN warrants for two years) will be free from defects in materials and workmanship, and will be in conformity with TN's specifications.

TN's warranty on products manufactured by or assembled for TN in accordance with a customer's specifications, is a five-year warranty that the goods conform to such specifications.

The warranty is invalidated if the goods have been subject to alterations, misuse, accident, Acts of God (e.g., damage by floods, lightning strikes, Etc.), tampering, improper maintenance, improper installation, or abuse. If the user is unsure about the proper means of installing or using the equipment, contact TN's free Technical Support or Network Design Services, which can be reached by:

Telephone 1.800.LAN.WANS or 612.941.7600
Fax 612.941.2322
E-mail techsupport@transition.com
Internet <http://www.transition.com>

THE ABOVE WARRANTY IS EXCLUSIVE AND EXTENDS ONLY TO PRODUCTS ASSEMBLED BY TRANSITION NETWORKS, INC. TO THE EXTENT PERMITTED BY LAW, TN DOES NOT MAKE AND DISCLAIMS ALL OTHER WARRANTIES, EXCEPT TITLE, EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF DESCRIPTION, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, AND ANY WARRANTY BASED UPON PRIOR WRITTEN OR ORAL REPRESENTATIONS REGARDING SUCH PRODUCTS MADE BY TN, ITS EMPLOYEES, AGENTS, OR REPRESENTATIVES.

B. Limitations and Exclusions

If the customer believes any goods sold by TN are defective and within the warranty period, the following general procedure will be followed:

1. Locate the serial number and delivery date of the item(s).
2. Notify TN within the warranty period.
3. TN will promptly issue a return authorization form for the goods.
4. Upon receiving the form, the customer will promptly return the item(s) at customer's own expense, shipped prepaid, to the distributor from which it was purchased, or directly to TN.

TN will only accept goods for return if the following conditions have been met:

1. A return form is obtained from TN.
2. The freight charges have been prepaid by the customer.
3. Goods are re-packed in their original packaging.


If under warranty TN shall, at its option, (1) repair the goods free of charge (2) replace the goods free of charge, or (3) accept the return of the item(s) and credit the current price to the reseller (within 90 days of purchase), or (4) if the goods are not under warranty, will repair the item(s) at a minimum charge of USD \$200 (two hundred U.S. dollars) per item.

THIS IS THE EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY. IN NO EVENT SHALL TRANSITION NETWORKS BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, WHETHER FOR BREACH OF ANY CONDITION OF SALE, FOR NEGLIGENCE, ON THE BASIS OF STRICT LIABILITY, CONTRACT, OR OTHERWISE AND IRRESPECTIVE OF WHETHER TN IS INFORMED BY CUSTOMER OF THE POSSIBILITY OF SUCH DAMAGES IN ADVANCE OF THIS SALE.


Networking the 0402 Ethernet Pocket Hub

The 0402 Pocket Hub can function as the network backbone in both simple and complex networks.

When centrally located in a small installation, the 0402 Pocket Hub alone provides a simple, economical network solution.




When linked to other 0402 Pocket Hubs or to other 802.3 compliant Ethernet repeaters, the Pocket Hubs function in complex Ethernet networks.




0402 Ethernet Pocket Hub Connectors and Status LEDs

RJ-45 Connectors




Four (4) 10BaseT RJ-45 jack connectors are located at one end of the 0402 Pocket Hub. The RJ-45 jacks support connection to shielded or unshielded 100 ohm twisted pair 10BaseT cable.

Power Supply Adapter Connectors



An external power supply adapter connector is located at the other end of the 0402 Pocket Hub. The power supply adapter connector supplies external power.

Status LEDs



Power and Link/Transmit status LEDs are located at the side of the 0402 Pocket Hub. The **Power** LED indicates connection to power. The **Link/ Transmit** LEDs track the four 0402 Pocket Hub connections to 10BaseT.

5. MAINTENANCE

WARNING: DO NOT, UNDER ANY CIRCUMSTANCES, open and attempt to repair the 0402 Pocket Hub or power supply adapter unit. Failure to observe this warning could result in personal injury or death from electrical shock.

NOTE: Failure to observe the above warning will immediately void the warranty.

Fault Isolation

If two network devices fail to communicate through the 0402 Pocket Hub, consider the following:

- Are the LEDs described in the previous section functioning properly?
- Do network devices have Link Integrity enabled?
- Do network devices communicate when the 0402 Pocket Hub is not installed between them?
- Is flat or “silver satin” wire used in site internal wiring?
- Are internal wiring patch cords, punch down blocks, and wall jacks properly pinned or configured?
- Is the AUI cable unbroken and properly connected?
- Are network interface cards properly configured?

Technical Support Contact


For assistance in fault isolation and in maintaining the 0402 Pocket Hub, contact:

Technical Support (800) 260-1312

or your local distributor.

4. OPERATION

The 0402 Pocket Hub normally requires no intervention beyond occasionally monitoring the Power and Link/Transmit LEDs.



Monitoring Power LED

The green **Power** LED is illuminated when the Pocket Hub is connected to power.

Monitoring Link/Transmit LEDs

Each of the green **Link/Transmit** LEDs, associated with one of the eight RJ-45 ports:

- is illuminated when a device is connected to the RJ-45 port
- flashes slowly as data is transmitted
- flashes quickly if the associated RJ-45 port has been automatically partitioned.

2. SITE CONSIDERATIONS

The site for the 0402 Ethernet Repeater Hub must provide:

- AC power outlet for each Hub
- Adequate ventilation
- Standard environmental conditions
- Isolation from electrical noise, including radio transmitters and broadband amplifiers, motors, high power electrical lines, or fluorescent light fixtures.

Additionally:

- The twisted pair cables should not run in the same conduit with power line cables.
- Phone lines should be separated from data cables.
- Flat or "silver satin" wires should not be used.

And:

- Since the 0400A Ethernet Pocket Hub functions as an Ethernet Repeater, the entire 0400A Ethernet Repeater Hub installation should comply with the IEEE Ethernet 802.3 specification, including segment number.
- RJ-45 connected cables should be configured as crossover or straight through according to installation requirements.

Ensuring Correct Segment Number


Ethernet 802.3 specifications define segment number, as well as cable characteristics. NOTE: A segment is the cable connection between cable interfaces in an Ethernet LAN.

Segment Number

When connecting Pocket Hubs, the transmission path between any two Data Terminating Equipment (DTE) terminals can consist of no more than five segments.

To assign segment numbers to cable connections:

1. Determine the two terminals in the network which are separated by the greatest number of segments.
2. Assign a segment path between the terminals by labeling the cable connected to one of the terminals "segment 1" and the segment connected to the other terminal "segment n" (n = total number of segments ≤ 5).
3. To verify that no segment paths contain more than n segments, assign segment paths and numbers to all other terminals.



Connecting Power to 0402 Pocket Hub

To power ON the 0402 Pocket Hub:


1. Locate the power receptacle on the back of the 0402 Pocket Hub.
2. Connect the 0402 Pocket Hub power connector end of the power supply adapter to the Pocket Hub.
3. Connect the external power connector end of the power supply adapter to external AC power.

NOTE: After the power supply adapter is connected to the 0402 Pocket Hub and to external power, the green **Power** LED is illuminated.

Connecting two Pocket Hubs


Use a **crossover** cable to connect Pocket Hubs.

Use a **straight through** cable to connect Pocket Hub to terminal devices.



Ensuring Correct 10BaseT Configuration


The 10BaseT cable and RJ-45 jacks for **Hub to Terminal** connections must be configured as **straight through**. The 10BaseT cable and RJ-45 jacks for **Hub to Hub** connections must be configured as **crossover**.



The two active pairs in a 10BaseT network are pins 1 & 2 and pins 3 & 6. Use only dedicated wire pairs (such as blue/white & white/blue, orange/white & white/orange) for the active pins.

Connecting Pocket Hub to Terminal Devices

Use a **straight through** cable to connect Pocket Hub to terminal devices.



Straight Through Cable at RJ-45 Plug

Hub	PC, transceiver, NIC, printer
RJ-45 Male	RJ-45 Male
1	1
2	2
3	3
6	6

Crossover Cable at RJ-45 Plug

Hub	Hub
RJ-45 Male	RJ-45 Male
1	3
2	6
3	1
6	2

3. INSTALLATION

NOTE: 0402 Ethernet Pocket Hub Link Integrity cannot be disabled. All devices connected to the Pocket Hub MUST have link functions enabled.

To install the 0402 Ethernet Pocket Hub:

- Unpack the 0402 Pocket Hub.
- Connect 10BaseT Cable to the 0402 Pocket Hub.
- Connect the 0402 Pocket Hub to power.

Direction is provided in the pages that follow.

Unpacking the 0403 Pocket Hub

The 0402 Ethernet Pocket Hub packing contents should include the following:

Item	Part Number
0402 Pocket Hub	E-TBT-HB-0402
Power Supply Adapter	3518, 3517, 3516, 3515, or 3514, (depending upon power configuration in country where installed)
User's Guide	7349

Connecting 10BaseT Cable

To connect 10BaseT Cable to Pocket Hub RJ-45 connectors:

1. Locate or build 10BaseT cables with the following characteristics:
 - 803.2 compliant (See page 14)
 - correct (straight through or crossover) cable configuration for site installation (See page 7)
 - male RJ-45 plug connectors installed at both ends of cable.
2. Connect male RJ-45 plug connector at one end of 10BaseT cable to Pocket Hub RJ-45 jack connector.
3. Connect male RJ-45 plug connector at other end of 10BaseT cable to DTE terminal RJ-45 jack connector (using straight through cable orientation) or to Pocket Hub RJ-45 jack connector (using crossover cable orientation).

Connecting to External Hub through Wall Outlet

Use a **crossover** cable to connect Pocket Hub to the wall plate.
Use a **straight through** cable to connect Pocket Hub to terminal devices.

